



Tuning in a new remote(12 button);

*Hold down the shift button and press the mix button and then release both buttons, a message will appear on the CCU display "**pairing...**" and the RPM bar graph will light up. Press and hold the resume button on the remote until the bar graph flashes indicating the remote is successfully paired.*